

25.5.1968

1) Fill existing space between bracket and edge laminate of the opening with the

same glue as in item A/2. Let glue harden.

- 2) Drill as shown on sketch two holes in each bracket in such a way that the bolts to be inserted in the holes go through the stiffener. Place washers both under bolt head and under nut and tighten nuts.

Required screws, nuts, washers, and the Araldit glue will be furnished by manufacturer without charge.